

Fiber Care

HANDLING INSTRUCTIONS



ALWAYS HANDLE PRECISE OPTICAL MEASUREMENT SYSTEMS **WITH CARE**



CAP END FACE WHEN CONNECTOR IS NOT IN USE



BARE FIBER SHOULD NOT SUPPORT THE **WEIGHT OF THE CONNECTOR**



INSPECT THE END FACE OF THE FIBER FOR DUST OR IMPERFECTIONS



AVOID ANY UNNECESSARY FORCE THAT MAY CAUSE THE FIBER TO **BEND SHARPLY AND BREAK**



CLEAN ANY DIRT FROM THE END FACE WITH ISOPROPANOL AND A LINT-FREE WIPE OR WITH THE FIBER CLEANING KIT

STORAGE



SHORT TERM
COILED DIAMETER
> 6 cm



LONG TERM
COILED DIAMETER
> 10 cm

provided by

 **LUMILOOP**
LASER-POWERED SENSOR SYSTEMS

www.lumiloop.de