

GTEM-2000

For emission and immunity testing according to IEC/EN 61000-4-20



Introduction

The GTEM cell is a TEM waveguide with the upper frequency limit extended to the GHz range. It is under consideration as an alternative measurement facility for both radiated emission and immunity measurements. It is included in the standard IEC 61000-4-20 "Emission and Immunity Testing in Transverse Electromagnetic (TEM) Waveguides".

Compared to other measuring methods like EMC test in anechoic chambers or OATS (Open Area Test Sites), GTEM-cells offer some significant advantages for the testing of small and medium sized EUT's (Equipment Under Test) up to a frequency range of 20 GHz. Quick turnarounds of the EUT as well as numerous testing variations are easy and fast to handle. Switching from emission to immunity testing requires only simple adjustments from receiver input to amplifier output.

Reliant EMC





You are irrespective of long waiting times associated with off-site test labs or weather and ambient delays that can occur at OATS facilities. Whether you are at the design qualification, pre-compliance, compliance, or production sampling stage, the GTEM is the right choice for you!













GTE	M-2000	
Height of septum in the back of the cell	Hh=2295 mm	
Distance of the testing section from back of cell along z axis	L _s =1540 mm	
Testing section dimensions [mm]	a = 2976, b = 3967, h = 2000, w = 2540	
Maximum testing volume (IEC 61000-4-20)	1800 x 2450 x 5400 mm (h-2h _{EUT}) x w x L	
Max. EUT volume	667 x 1470 x 3240 mm	h/3 x 0.6 w x 0.6 L
Maximum EUT testing volume (0-6 dB)	measurement results	
H _{EUT}	667 mm	h/3
Min. h _{EUT}	100 mm	0.05 h
Door (LxH)	Standard: 100 x 160 cm On request: *160 x 160 cm	
RF input connector	N Type	
Frequency range	DC to 20 GHz	
Max. input power	1000 W (depending on the frequency)	
Applications	Measuring of radiating emission and radio frequency immunity tests, calibration of antennas and field probes, test and measuring of mobile phones, shielding effectiveness of materials.	



Technical specifications		
Frequency range	0.01 MHz - 20 GHz*	
Septum height	2000 mm	
Max EUT size (LxWxH)	1800 x 2450 x 5400 mm	
Defined test volume	667 x 1470 x 3240 mm	
Typical VSWR	1:1.2	
Typical VSWR at critical frequency	< 1:1.6	
Max. input power, W continuous/*pulsed	1 kW/*1.5 kW	
Input connector	N UG-21 *(optional: 7/16")	
Nominal impedance	50 Ohm	
Mechanical		
*Window in the door	240 mm diameter (approx.)	
Empty technical panel	N.3 Diameter 280 mm	
Outer dimensions (LxWxH)	933 x 480.5 x 306 cm	
Door (WxH)	Standard: 100 x 160 cm	
	Optional: *160 x 160 cm	
Weight	approx. 1500 kg	
Wheeled undercarriage	25 cm, high	
*Options	8	
Electrical		
Mains connectors	Fix/CEE	
Main switch	magneto-thermal 16A mono phase	
Input socket plug	16 Aac (mono phase + ground)	
Output socket EUT tape	16 Ac (mono phase + ground)	
Additional EUT sockets	optional	
Ground connection	M6 bolt, always connected	
AC filter wires (mono phase + ground)	15 A, 2 poles	
Channel for fiber optic leads	3 couple	
RF feed-thru connectors	N.1 N female	
RF feed-thru SMA connectors	N.2 female SMA	
Technical panel pre-drilled for options	supplied	
*Options		
- Electrical safety interlock		
- Indoor lighting: 50W halogen or 20W LED		
- I/O 9-pole signal filter (DB9)		
- I/O 25-pole signal filter (DB25)		
- Custom filters on demand		
- Channel for fiber optic leads (6 couple)		
- Additional RF feed-thru N connector		
- Additional RF feed-thru SMA connector		
- RJ11 (RJ9) feed-thru connector		




Installation manual and general safety instructions

The GTEM (Giga Hertz Transverse Electromagnetic) cell is a precision electromagnetic compatibility (EMC) test instrument primarily intended for use as radiated immunity and radiated emission test facility without environmental electromagnetic interference. The cell is electrically similar to a coaxial cable with one side open (the apex) and other side closed on the impedance of the generator or receiver connected. In this case with a multimeter appears a 50 Ohm resistance.

Measurement setup

The setup for emission measurements in a GTEM cell is shown in Fig. 1. The EUT is placed inside the GTEM and its radiation is measured with a receiver. The receiver can be software controlled and some software that includes the GTEM to OATS correlation is commercially available.





Testing Volume




Fig.2 - Maximum EUT size and maximum size of the usable test volume in a GTEM cell, longitudinal section




Fig.3 Maximum EUT size and maximum size of the usable test volume in a GTEM cell, cross section



Calculating Power Required - Theory

Basically, we have to consider the volts per meter, the height of the septum, the allowance of voltage peaks caused by amplitude modulation and the flatness with frequency. For flatness, we generally allow 3 dB, this only takes effect after the first resonance point. The example above shows 10 V/m with a GTEM-2000.

GTEM-2000

Septum height = 2 m

Flatness = 3 dB = 2

Power required = $[(E \times h)^2 / R] \times Flatness \times Modulation Allowance$

Where:

E(V/m) = required field strength:

h (m) = septum height

R = GTEM input impedance (50 Ohm)

Power required = $[(10 \times 2)^2 / 50] \times 2 \times 3.24 = 51.84$ Watt

GTEM-2000 Power requirement

Field Strenght E	Flatness	Modulation allowance	Required power modulated	Required power CW
V/m	3dB = 2	80% AM, 1kHz	Watts	Watts
3	2	3.24	4.67	1,44
10	2	3.24	51.84	16
30	2	3.24	466.56	144


Factory controls

Performance test:


A verification test was performed on site of the installation with a Rhode & Schwarz FSH6 spectrum analyzer and its SWR bridge accessory.



REFLECTION COEFFICIENT: S11 magnitude of GTEM-2000 in the range 10-6000MHz



REFLECTION COEFFICIENT: S11 magnitude of GTEM-2000 in the range 10-3000MHz





Guaranteed reflection coefficient S11

GTEM-2000			
Reflection coefficient S11	S11 accuracy magnitude/phase		
<-14 dB in 100 MHz - 3.8 GHz	± 2 dB / 1 degrees		

Filter units





Feed-thru filters

Mains line filter

Component list:

16A, 250V IEC input power line panel male socket (external) 16A, 250V SCHUCO output power line female tape (internal)

FILTER CONCEPTS Mod. 0114/11761 250Vac 2x15A, 50/60 Hz

L=2x60uH+2x8.3mH, Cx=2x2,2uF, Cy=2x0.0068uF, R=1.2MOhm

- N.2 Feed-thru filter EPCOS 16A 250Vac
- N.1 Magnet-thermally switch GEWISS Mod. C-16, 16Amp.* Mains switch
- N.1 Switch SCHNEIDER with Lamp Mod: 6A 250Vac for external Illumination



WARNINGS! READ BEFORE USING

HANDLE CAREFULLY

The GTEM cell is professional test equipment intended for EMC emissions and immunity test purposes operated by trained personnel. Some care are necessary:

- Don't push or pull the apex to move the cell, move only from the frame trolley.
- Before move the cell, loosen the unlock the wheel brake than when you finish lock again.
- Open or close the door softly. Handle carefully.
- Insert always straight the N and SMA connectors, don't tight too much, it is not necessary!
- One N type corner adaptor connector is supplied to protect the apex, please don't remove it. If it brokes replace with one of the same quality.

RADIO FREQUENCY RADIATION

Personnel should not be exposed to the microwave energy which may radiate from this device. All inputs or output RF connection gaskets must be leak proof. Never look inside or leave doors open when this device is energized!

ELECTROMAGNETIC FIELD

Strong RF levels may cause de-magnetization and interference to others services. Operate always with the door closed and keep sensitive devices far from the door.

SHOCK HAZARD

Accidental short circuit or leakage current may occurs: Supply the unit through magneto-thermal differential switches lines. Keep always the GTEM cell grounded also with power supply disconnected. During normal tests operation connect energy only with the door closed.

ELECTROSTASTIC DISCHARGE

To avoid ESD keep always the GTEM cell grounded fitted with a permanent earth 16 mmq, wire conductor.

DANGER

Risk of injury at hands and head or cuts around the metallic surfaces of the chamber may occur. Leave around the cell a free area from obstacles.

MAINTENANCE

Verify periodically:

- the status of the door gasket,
- I/O connectors integrity.
- Oil the wheels of the trolley and the door hinges.

Clean inside the chamber excess of dust with a vacuum cleaner.

Protect metallic surfaces against **corrosion**, clean it with a soft cloth wet of Vaseline, Silicon or Paraffin oils. Avoid cleaning with water based products or chlorine solutions!



Maintenance

- When you are not operating live partially open the door avoiding stressing too much the gasket (they could take "memory form" reducing the shielding properties).
- Avoid touching the anechoic pyramids with the fingers or objects as they can be damaged easilv.
- Take care at the N input connector, do not remove the protection angle adaptor, if damaged occurs replace urgently the adaptor with one similar: straight or angular just to save the input connector.
- For cleaning purposes remove before any power supply source from the GTEM cell, then use only a wet of water added with soft detergent tissue for the window, avoid aggressive products: they can damage the meta-acrylate glass.
- Periodically remove dust inside the cell with a vacuum cleaner

Troubleshooting

No power supply in the plugs : fuse interrupted in the socket (replace with the same value 16A to protect the line filter) or magneto-thermall switch off.

No field with RF power applied: pin of the corner coaxial adaptor broken: replace urgently with a similar one

Additional info

Power supply: when necessary connect the AC 230V or 400V power cord, verify the presence of differential switch and magneto-thermal switches.

Load: Do not apply over load to the line filter: remember the max. load is 16A for the plug and 10Amps for the banana jacks.

Ground: A ground connection is necessary for your safety: please connect a 16mm² wire at the building earth system permanently by the screw placed down the filter box. Verify periodically the status of the connection. Keep in mind that the metallic structure in case of leackage is conductive!

Door: During immunity test the door (if necessary) could remain also opened; the field losses are negligible and the result of the test do not suffer a lot.

Additional holes: You can make feed-throught passages only on the technical panel (remove it if necessary)



RF Max Power input: No care are necessary, the terminations are over dimensioned, the limit is 1400W and Peack pulse power up to 2,5KW with operating temperature up to 100°C.

Warranty

All the parts are covered from guarantee for a period of 1 year (2 years for the INOX steel optional model) except from wear and tear parts like: gasket, coaxial type N or SMA connectors, anechoic pyramids.

